COOKTOP PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)

30" GAS FREESTANDING
STANDARD CLEAN RANGE
ELECTRONIC IGNITION



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT98014964	Instructions, Installation
	LIT98015589	Installation Instr (Template)
	LIT98014376	Guide, Use & Care
	LIT98007130	Safer Cooking Tips
	LIT98007032	Tech Sheet
2		Cooktop
	98009677	White
	98009678	Biscuit
3		Panel, Manifold
	98009455	White
	98009448	Biscuit
4		Knob, Burner (4)
	98006102	White
	98008208	Biscuit
5		Knob, Thermostat
	98008321	White
	98008322	Biscuit
6		Grate, Burner (2)
	98009286	Black
	98013747	Gray
7	98004722	Clip, Cooktop (2)
8	98014544	Wire, Ground
9	98013389	Bumper, Cooktop
10	98005000	Screw (3)
11		Cap, Burner
	98005518	Black
	98007065	Gray
12	98007225	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BACKGUARD PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	98005336	White Left
	98008274	Biscuit Left
	98005337	White Right
	98008275	Biscuit Right
2	98006083	Cover, Backguard
3		Panel, Backguard
	98008006	White
	98008279	Biscuit
4	98004219	Screw

MANIFOLD PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	98004410	Burner, Top (4)
2	6610243	Venturi, Front (2)
3	98005500	Brkt., Venturi (4)
4	6610244	Venturi, Rear (2)
5	6610341	Spark Module
6	98007411	Regulator
7	98007192	Cover, Module
8	98015099	Spreader, Flame
9	98006632	Screw
10	98012138	Burner, Oven
11	98006633	Screw
12	98014545	Harness, Switch
13	98014893	Valve, Oven
14	98006633	Screw
15	98005574	Valve, Burner (4)
16	98005521	Bolt, Valve Mtg
17	98013577	Pipe, Manifold
18	98009179	U−Nut
19	98003984	Thermostat
20	98005663	Bolt, T−Stat Mtg
21	98005652	Igniter, Oven Oven Pilot)
22	98007132	Washer, Valve (4)
23	98007428	Tubing (Regltr to Oven Valve)
24	98013314	Locator, Burner
25	98007410	Bracket, Regulator
26	98007431	Fitting 3/8to9/16
27	98013634	Screw
28	1180823	Screw
31	98007429	Tubing, Inlet
32	98007430	Fitting 1/4to9/16
33	98005026	Clip
34	98005659	Screw
35	98004484	Screw
36		Igniter, Top
	98014514	RF
	98014515	LF, RR
	98014516	LR
37	98007187	Clip, Igniter

FOLLOWING PARTS NOT ILLUSTRATED

98013674	LP Spud Kit (For Use With LP)
98013675	Natural Spud Kit (For use with Natural Gas)

CHASSIS PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	98003799	Flue Box
2	98013690	Clip, Flue
3	98014398	Shield, Insulation
4		Panel, Side (2)
	98010042	White
	98010045	Biscuit
5	98005502	Clip, Oven Bottom
6	98006710	Counterweight
7	98006739	Wire, Brick
8	98006750	Frame, Front
9	98005306	Foot, Front (2)
10	98005307	Foot, Rear (2)
11	98004449	Bottom, Oven
12	98005642	Clip, Bulb (2)
13	98003847	Baffle, Base
14	98003830	Rail, Base (2)
15	98012175	Support, Burner
16		Button, Plug
	98007388	25/32"
	98007390	15/32"
17	98004723	Bumper (2)
18	98009179	U−Nut
19	98015736	Baffle, Side (2)
20	98015100	Back, Main
21	98014828	Seal, Oven
22	98006633	Screw
23	98007193	Washer
24	98007126	Base, Foot
25	98006632	Screw
27	98007191	Shield, Lower
28	98006631	Screw
29	98014532	Cord, Power
30	98005026	Clip, Tubing
31	98015346	Foil, Side (2)
32	98006634	Screw
33	98004447	Top, Oven
34		Side, Oven
	98004452	Right Hand
	98004451	Left Hand
35	98005768	Back, Oven
36	98010053	Support, Rear
37	98014104	Cover, Socket
38	98014105	Cover, Valve
40	98007205	Cap, Insulation

INSULATION

	98014360	Insulation, Wrap
	98004294	Tie, Insulation
	98004286	Insulation, Back

OVEN & BROILER PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	98014135	Rack, Oven (2)
2	98003480	Grill, Broiler
3	98003479	Pan, Broiler
4	98013751	Rack, Broiler
5	98004761	Bracket, Rack
6	98004715	Guide, Rack (4)
7	98004052	Bumper, Door (2)
8		Screw
	98006727	White
	98008169	Biscuit
9	98004698	Liner, Door
10	98004773	Spacer
11	98015234	Insulation, Door
12		Panel, Door
	98009337	White
	98009336	Biscuit
13		Handle, Brlr Door
	98006623	White
	98008266	Biscuit
14	98006644	Screw
15	98003790	Hanger, Brlr Door
16	98008341	Cover, Guide
17	98006633	Screw
18	98003791	Support, Hinge
19		Spring, Broiler
	98008380	Right Hand
	98008379	Left Hand
20	98004219	Screw
21	98007396	Spacer
22	98004053	Pin, Hinge (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8533843	Screw
3	98010183	Liner, Door
4	98006853	Insulation, Door
6	98006897	Hinge, Door (2)
8		Panel, Oven Door
	98009488	White
	98013502	Biscuit

Illus. No.	Part No.	DESCRIPTION
10		Handle, Oven Door
	98006181	White
	98008289	Biscuit
11	98004650	Nut, Push

Illus. No.	Part No.	DESCRIPTION
12	98004993	Screw
15		Retainer
	98004564	Right
	98004629	Left
16	98004219	Screw

MISCELLANEOUS PARTS

For Model: SF3020EKQ3, SF3020EKT3
(Designer White) (Designer Biscuit)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
8316781	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

WIRING HARNESS PARTS

98014534	Harness, T−Stat
3196696	Clip, Wire
98005894	Clamp, Cord
98015022	Bushing, Snap (2)
3391018	Cable Tie−Push Mnt

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ANTI−TIP KIT

98017833	Anti−Tip Kit

Miscellaneous

814381	Pin Kit−Dr Removal